



# Sure Grip Pad

## Installation Instructions

**PART# A.5.10.2372**

(Fits: ATI's Draganov Fiberforce Stocks)

**Advanced Technology**  
INTERNATIONAL

Thank you for purchasing an ATI product!



### ADHESIVE PAD INSTALLATION

**Point the rifle in a safe direction and place the safety in the "on" position. Next remove the magazine, pull back the bolt, and carefully inspect the chamber to be sure the rifle is unloaded.**

#### Step #1

Begin by using the supplied alcohol swab to clean the cheekrest area on both sides of the stock.



Figure 1

#### Step #3

Continue to align the pad to the stock. Keep slight tension on the pad and bring the the pad around the surface of the cheekrest.



Figure 3

#### Step #2

Wait 30 minutes until the alcohol is dried. Remove the backing from the adhesive pad and align the pad to the stock.



Figure 2

#### Step #4

Use your thumb to remove any air bubbles in the pad and to firmly press and secure the adhesive pad onto the cheekrest.



Figure 4

**Advanced Technology International • Made In the USA • Limited Lifetime Warranty**

2733 West Carmen Ave • Milwaukee, WI 53209

Toll Free: 800.925.2522 • Fax: 414.464.3112

**www. ATlgunstocks.com**