



Mossberg Pump Forend

Installation Instructions

PART# MOS0300

(Fits: 12 Ga Mossberg 500/535/590/835)

Thank you for purchasing an ATI product!

Advanced Technology
INTERNATIONAL



Forend Installation

Forends on the Maverick 88, the new Mossberg 500A, B and C and the new Mossberg 835 cannot be replaced because the action bars are attached to the forend.

Step #1

Cycle the action once to make sure the hammer is cocked. Make sure the safety is in the "on" position.

Step #2

Depress the slide release and pull the forend halfway back. Next loosen the magazine cap and remove the barrel.



Figure 1

Step #3

Using an ATI mag socket wrench (sold separately), loosen and remove the castle nut from the action slide assembly. Now, remove the existing forend from your Mossberg shotgun by sliding it off towards the front.



Figure 2

Step #4

Install the new ATI forend to your Mossberg shotgun by sliding it over the action slide assembly and towards the rear. Make sure the forend is aligned correctly before continuing to step #5.



Figure 3

Step #5

Re-insert the castle nut onto the action slide, and tighten using a mag socket wrench. Now, re-insert the barreled action, and tighten the magazine cap so it is in the locked position.



Figure 4

Advanced Technology International • Made In the USA • Limited Lifetime Warranty
2733 West Carmen Ave • Milwaukee, WI 53209
Toll Free: 800.925.2522 • Fax: 414.464.3112

www.ATIGunstocks.com